SHOE BOX-LED LIGHT
ADJUSTABLE WATTAGE/CCT

c UL us
LISTED
E468007

150W/200W/240W



c UL us LISTED E468007

Lighting Parameters

Part No.	Input Voltage	Frequency	Power	Rated Current
	AC100-277V	50/60Hz	150W/ 200W/ 240W	
SHOEBOX-SL0820-240W-H3-TCP				2.64A

Lamp Bead Model	SMD 3030
Certificates	UL,CUL
Lighting Angle	TYPE Ⅲ-M / TYPE IV-S / TYPE V
Lighting Efficiency	130Lm/W
Color Rendering Index	Ra>80
Working Temperature	-40℉ ~+113℉ / -40℃ ~ +45℃
Storage Temperature	-40 ℉ ~+158 ℉ / -40℃ ~ +70℃
Environment Location	WET LOCATIONS（IP65)
Life span	﹥50000H
Lamp shell	BROWN / BLACK
Accessories options	Photocell；Shorting cap；Surge protector
	PIR senser；Motion sensor；Bluetooth sensor
	Waterproof cover plate of photocell hole
Accessories mounting brackets	TYPE A (Slip-fitter)  TYPE A2 (Slip-fitter)  TYPE B (Square/Round pole mount with slip-fitter function) 
	TYPE B2 (Square/Round pole mount with slip-fitter function)  TYPE C (Square/Round pole mount)  TYPE D (Trunnion) 
	TYPE E (Yoke)  TYPE F  TYPE G  TYPE H 

Operation Instruction of Rotating Optical Lens

Step 1.First loosen the screws on the lens screws (total 24PCS), as shown in the figure;



Step 2.Remove the optical lens, rotate it clockwise or counterclockwise to a desired angle, as shown in the figure;



Step 3.Put back the adjusted optical lens, lock screws back, as shown in the figure.



Watts selected Operation Manual

Notes: CCT selectable only and Wattage selectable only versions are also available.

1. Take of the waterproof rubber cover from the wattage-box.



2. Select the wattage by using the slide switch.



3. Put back the waterproof rubber cover.



Extended function

(Cover plate, Photocell, Shorting cap)



(Surge,lighting arrester)

(Respirator)

(PIR sensor， Motion sensor)



c UL us LISTED E468007